

- 1. The receiver must stay in place with the 20 pin plugged in order for the SWI-X to work with the steering wheel controls.
- 2. You may remove the Radio and Tape deck and use the 10 pin plug.
- 3. Only 4 wires will be used for the push buttons on steering wheel.
- 4. Note that the buttons can be assigned any IR remote function and not what is labeled on the switches.
- 5. The volume knob can not be retained.