


HYUNDAI

****READ THIS FIRST****




iPod

Changing Modes:

Press the XM button to toggle through the available Media Gateway Sources. SAT 1*, SAT 2*, SAT 3*, HD FM 1*, HD FM 2*, HD FM 3*, HD AM*, iPod and AUX.

* If equipped.

XM Button-Press to cycle through sources within the PXAMG (SAT, HD, iPod, Aux1, Aux2)



Tune knob

- Turn Clockwise to advance to the next track
- Turn Clockwise to move forward through the browse menu
- Turn Counter-clockwise to change to previous track
- Turn Counter-clockwise to move backwards through the browse menu

Preset # 2
Press to enter the Browse menu.
Press to select the displayed option in the Browse menu.

Preset # 3
Press to exit the Browse menu.

Browsing Example:

To select the song "Star-Spangled Banner" through the Artist category

1) Press Preset #2 to enter the Browse menu. The radio will display "PL:LIST"

2) Turn the Tune Knob until the radio displays "AR:ARTIST" Press Preset #2 to select. The radio will show "AR:All"

3) Turn the Tune Knob until "Francis Scott Key" is displayed. Press Preset #2 to select. The radio will show "AL:All"

4) Turn the Tune Knob until "Patriot Hits Vol. 1" is displayed Press Preset #2 to select The radio will show "TR:" followed by the first track name in the selected album.

5) Turn the Tune Knob until "Star-Spangled Banner" is displayed Press Preset #2 to select The song will begin to play, and the radio will show the track title

(Actual Radio Appearance may differ from representation.)
QRC015

HYUNDAI




****READ THIS FIRST****

Changing Modes:

Press the XM button to toggle through the available Media Gateway Sources. SAT 1*, SAT 2*, SAT 3*, HD FM 1*, HD FM 2*, HD FM 3*, HD AM* , iPod and AUX.

* If equipped.



HD RADIO EXAMPLE

To select an HD radio station.

Press 'SEEK ^' to get to the desired station. The Radio will auto lock on to an HD Radio Station if available
example:92.5 HD1 MHZ
When locked into an HD Radio Station, press 'SEEK ^' up to access multi-cast HD Station(s). (if available)
example 92.5 HD2 MHZ

To store a radio station into preset memory.

Press "SEEK ^" to get to the desired station. Press and hold the desired preset button (1-6) until "PR SAVED" is displayed.

To recall a station stored into preset memory.

Recall a preset station by pressing its corresponding preset button, (1- 6)

(Actual Radio Appearance may differ from representation.)